

# ICON Frozen-Ambient Combo Shipper

(Qualified for 48 hour transits)



## Pack Ambient Compartment

Central Laboratories



Select Frozen- Ambient Shipper.



Remove lid from ambient compartment.



Remove 1 of the polar packs.



Place 95kPa specimen bag on top.



Place polar pack on top of 95kPa bag.



Secure lid on compartment.



Fold side flaps of compartment.



Secure compartment lid.

Instructions for packing the frozen compartment are provided on the following page.



